
REPLACEMENT SHEET Appl. No. 10/605,990 BUR920029022US1 (AJC) Peter A. Habitz 1/5



Capacitance Matrix =
$$C = \begin{bmatrix} C_{11}C_{12} & C_{13} \\ C_{21}C_{22} & C_{23} \\ C_{31}C_{32} & C_{33} \end{bmatrix}$$

coupling capacitances $= C_{ni}$, where n, i = conductor numbers

total capacitance = $C_{ntot} = \sum_{i=1}^{N} C_{ni}$, where N = the number of conductors

Figure 1a

REPLACEMENT SHEET Appl. No. 10/605,990 BUR920029022US1 (AJC) Peter A. Habitz 2/5




FIG. 1b

REPLACEMENT SHEET Appl. No. 10/605,990 BUR920029022US1 (AJC) Peter A. Habitz 3/5





FIG. 2

REPLACEMENT SHEET Appl. No. 10/605,990 BUR920029022US1 (AJC) Peter A. Habitz 4/5



REPLACEMENT SHEET Appl. No. 10/605,990 BUR920029022US1 (AJC) Peter A. Habitz 5/5




FIG. 4